



# How to install GORE™ Automotive Vents

## BEFORE YOU BEGIN:

Always wash hands before working with vents.

Make sure work area is clean and uncluttered.

## 1. PREPARATION

Inspect vent for defects.  
Clean mounting surface with alcohol if needed.



## 2. POSITIONING VENT

Using target frame as a guide, place vent squarely inside frame.



## 3. HAND COMPRESSION

Press around edge of vent 1.5 times.



## 4. MACHINE COMPRESSION

Place lamp in the seat of the compression device and compress once. Remove lamp and inspect.

